



OM-233 865F

2009-05

Processes




Multiprocess Welding

Description



Arc Welding Power Source

XMT™ 350 CC/CV Auto-Line™ CE



OWNER'S MANUAL



Visit our website at

www.MillerWelds.com

File: MULTIPROCESS



From Miller to You

Thank you and congratulations on choosing Miller. Now you can get the job done and get it done right. We know you don't have time to do it any other way.

That's why when Niels Miller first started building arc welders in 1929, he made sure his products offered long-lasting value and superior quality. Like you, his customers couldn't afford anything less. Miller products had to be more than the best they could be. They had to be the best you could buy.

Today, the people that build and sell Miller products continue the tradition. They're just as committed to providing equipment and service that meets the high standards of quality and value established in 1929.

This Owner's Manual is designed to help you get the most out of your Miller products. Please take time to read the Safety precautions. They will help you protect yourself against potential hazards on the worksite. We've made installation and operation quick and easy. With Miller you can count on years of reliable service with proper maintenance. And if for some reason the unit needs repair, there's a Troubleshooting section that will help you figure out what the problem is. The parts list will then help you to decide which exact part you may need to fix the problem. Warranty and service information for your particular model are also provided.



Miller Electric manufactures a full line of welders and welding related equipment. For information on other quality Miller products, contact your local Miller distributor to receive the latest full line catalog or individual catalog sheets.



Working as hard as you do – every power source from Miller is backed by the most hassle-free warranty in the business.



TABLE OF CONTENTS

| | |
|--|-----------|
| SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING | 1 |
| 1-1. Symbol Usage | 1 |
| 1-2. Arc Welding Hazards | 1 |
| 1-3. Additional Symbols For Installation, Operation, And Maintenance | 3 |
| 1-4. California Proposition 65 Warnings | 4 |
| 1-5. Principal Safety Standards | 4 |
| 1-6. EMF Information | 4 |
| SECTION 3 – DEFINITIONS | 5 |
| 3-1. Manufacturer's Warning Label Definitions | 5 |
| 3-2. WEEE Label (For Products Sold Within The EU) | 7 |
| 3-3. Symbols And Definitions | 7 |
| SECTION 3 – INTRODUCTION | 8 |
| 3-1. Specifications | 8 |
| 3-2. Volt-Ampere Curves | 8 |
| 3-3. Duty Cycle And Overheating | 9 |
| SECTION 4 – INSTALLATION | 10 |
| 4-1. Serial Number And Rating Label Location | 10 |
| 4-2. Selecting a Location | 10 |
| 4-3. Connecting 3-Phase Input Power | 11 |
| 4-4. Electrical Service Guide | 12 |
| 4-5. Weld Output Terminals And Selecting Cable Sizes | 13 |
| 4-6. Remote 14 Receptacle Information | 14 |
| 4-7. 115 Volts AC Duplex Receptacle And Circuit Breakers | 14 |
| 4-8. Optional Gas Valve Operation And Shielding Gas Connection | 15 |
| SECTION 5 – OPERATION | 16 |
| 5-1. Front Panel Controls | 16 |
| 5-2. Meter Functions | 17 |
| 5-3. Mode Switch Settings | 17 |
| 5-4. Lift-Arc Trigger Hold TIG | 18 |
| 5-5. Stick Start Procedure | 18 |
| SECTION 6 – MAINTENANCE & TROUBLESHOOTING | 19 |
| 6-1. Routine Maintenance | 19 |
| 6-2. Blowing Out Inside Of Unit | 19 |
| 6-3. Voltmeter/Ammeter Help Displays | 20 |
| 6-4. Troubleshooting | 20 |
| SECTION 7 – ELECTRICAL DIAGRAM | 22 |
| SECTION 8 – PARTS LIST | 24 |
| WARRANTY | |



DECLARATION OF CONFORMITY

for European Community (CE marked) products.

ITW Welding Products Group, Via Privata Iseo 6/E, 20098 San Giuliano, Milan, Italy. declares that the product(s) identified in this declaration conform to the essential requirements and provisions of the stated Council Directive(s) and Standard(s).

Product/Apparatus Identification:

| Product | Stock Number |
|------------------|--------------|
| XMT 350 CC/CV CE | 907371 |

Council Directives:

- 2006/95/EC Low Voltage
- 2004/108/EC Electromagnetic Compatibility
- 2006/42/EEC Machinery Directive

Standards:

- IEC 60974-1 Arc Welding Equipment - Welding Power Sources: edition 3, 2005-07.
- IEC 60974-10 Arc Welding Equipment - Electromagnetic Compatibility Requirements: edition 1.1, 2004-10.

EU Signatory:

April 23, 2009

Mark Lowther

Date of Declaration


EUROPEAN DIRECTOR, TECHNOLOGY & PRODUCT DEVELOPMENT


SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING

som_2007-04

 Protect yourself and others from injury — read and follow these precautions.

1-1. Symbol Usage

 **DANGER!** – Indicates a hazardous situation which, if not avoided, will result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.

 Indicates a hazardous situation which, if not avoided, could result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.


NOTICE – Indicates statements not related to personal injury.

 Indicates special instructions.



This group of symbols means Warning! Watch Out! ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards.

1-2. Arc Welding Hazards

 The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-5. Read and follow all Safety Standards.

 Only qualified persons should install, operate, maintain, and repair this unit.

 During operation, keep everybody, especially children, away.



ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present: in damp locations or while wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or when there is a high risk of unavoidable or accidental contact with the workpiece or ground. For these conditions, use the following equipment in order presented: 1) a semiautomatic DC constant voltage (wire) welder, 2) a DC manual (stick) welder, or 3) an AC welder with reduced open-circuit voltage. In most situations, use of a DC, constant voltage wire welder is recommended. And, do not work alone!
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.

- Always verify the supply ground – check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first – double-check connections.
- Keep cords dry, free of oil and grease, and protected from hot metal and sparks.
- Frequently inspect input power cord for damage or bare wiring – replace cord immediately if damaged – bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or poorly spliced cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Do not touch electrode holders connected to two welding machines at the same time since double open-circuit voltage will be present.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal.

SIGNIFICANT DC VOLTAGE exists in inverter-type welding power sources after removal of input power.

- Turn Off inverter, disconnect input power, and discharge input capacitors according to instructions in Maintenance Section before touching any parts.



HOT PARTS can cause severe burns.

- Do not touch hot parts bare handed.
- Allow cooling period before working on gun or torch.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.



FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use local forced ventilation at the arc to remove welding fumes and gases.
- If ventilation is poor, wear an approved air-supplied respirator.
- Read and understand the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watch-person nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.

- Wear an approved welding helmet fitted with a proper shade of filter lenses to protect your face and eyes when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash, glare and sparks; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (leather, heavy cotton, or wool) and foot protection.




WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and explosions. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Do not weld where flying sparks can strike flammable material.
- Protect yourself and others from flying sparks and hot metal.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared according to AWS F4.1 (see Safety Standards).
- Do not weld where the atmosphere may contain flammable dust, gas, or liquid vapors (such as gasoline).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock, sparks, and fire hazards.

- Do not use welder to thaw frozen pipes.
- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.
- After completion of work, inspect area to ensure it is free of sparks, glowing embers, and flames.
- Use only correct fuses or circuit breakers. Do not oversize or bypass them.
- Follow requirements in OSHA 1910.252 (a) (2) (iv) and NFPA 51B for hot work and have a fire watcher and extinguisher nearby.




FLYING METAL or DIRT can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.




BUILDUP OF GAS can injure or kill.

- Shut off shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



MAGNETIC FIELDS can affect Implanted Medical Devices.


- Wearers of Pacemakers and other Implanted Medical Devices should keep away.
- Implanted Medical Device wearers should consult their doctor and the device manufacturer before going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations.



NOISE can damage hearing.

Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



CYLINDERS can explode if damaged.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder – explosion will result.
- Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Use the right equipment, correct procedures, and sufficient number of persons to lift and move cylinders.
- Read and follow instructions on compressed gas cylinders, associated equipment, and Compressed Gas Association (CGA) publication P-1 listed in Safety Standards.

1-3. Additional Symbols For Installation, Operation, And Maintenance




FIRE OR EXPLOSION hazard.

- Do not install or place unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.




FALLING UNIT can cause injury.

- Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories.
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.




OVERUSE can cause OVERHEATING

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.



FLYING SPARKS can cause injury.

- Wear a face shield to protect eyes and face.
- Shape tungsten electrode only on grinder with proper guards in a safe location wearing proper face, hand, and body protection.
- Sparks can cause fires — keep flammables away.



STATIC (ESD) can damage PC boards.

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.



MOVING PARTS can cause injury.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.




WELDING WIRE can cause injury.

- Do not press gun trigger until instructed to do so.
- Do not point gun toward any part of the body, other people, or any metal when threading welding wire.




MOVING PARTS can cause injury.

- Keep away from moving parts such as fans.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Have only qualified persons remove doors, panels, covers, or guards for maintenance as necessary.
- Reinstall doors, panels, covers, or guards when maintenance is finished and before reconnecting input power.




READ INSTRUCTIONS.

- Read Owner's Manual before using or servicing unit.
- Use only genuine replacement parts from the manufacturer.



H.F. RADIATION can cause interference.


- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.




ARC WELDING can cause interference.


- Electromagnetic energy can interfere with sensitive electronic equipment such as computers and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.

1-4. California Proposition 65 Warnings


 **Welding or cutting equipment produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code Section 25249.5 et seq.)**

 **Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.**

For Gasoline Engines:

 **Engine exhaust contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.**

For Diesel Engines:

 **Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**

1-5. Principal Safety Standards

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping, American Welding Society Standard AWS F4.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, P.O. Box 9101, Quincy, MA 02269-9101 (phone: 617-770-3000, website: www.nfpa.org and www.sparky.org).

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 4221 Walney Road, 5th Floor, Chantilly, VA 20151 (phone: 703-788-2700, website: www.cganet.com).

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 5060 Mississauga,

Ontario, Canada L4W 5NS (phone: 800-463-6727 or in Toronto 416-747-4044, website: www.csa-international.org).

Safe Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 25 West 43rd Street, New York, NY 10036-8002 (phone: 212-642-4900, website: www.ansi.org).

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, from National Fire Protection Association, P.O. Box 9101, Quincy, MA 02269-9101 (phone: 617-770-3000, website: www.nfpa.org).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250-7954 (phone: 1-866-512-1800) (there are 10 Regional Offices—phone for Region 5, Chicago, is 312-353-2220, website: www.osha.gov).

1-6. EMF Information

Considerations About Welding And The Effects Of Low Frequency Electric And Magnetic Fields

Welding current, as it flows through welding cables, will cause electromagnetic fields. There has been and still is some concern about such fields. However, after examining more than 500 studies spanning 17 years of research, a special blue ribbon committee of the National Research Council concluded that: "The body of evidence, in the committee's judgment, has not demonstrated that exposure to power-frequency electric and magnetic fields is a human-health hazard." However, studies are still going forth and evidence continues to be examined. Until the final conclusions of the research are reached, you may wish to minimize your exposure to electromagnetic fields when welding or cutting.

To reduce magnetic fields in the workplace, use the following procedures:

1. Keep cables close together by twisting or taping them, or using a cable cover.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.
4. Keep welding power source and cables as far away from operator as practical.
5. Connect work clamp to workpiece as close to the weld as possible.

About Implanted Medical Devices:

Implanted Medical Device wearers should consult their doctor and the device manufacturer before performing or going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations. If cleared by your doctor, then following the above procedures is recommended.


SECTION 2 – DEFINITIONS

2-1. Manufacturer's Warning Label Definitions




Warning! Watch Out! There are possible hazards as shown by the symbols.

- 1 Electric shock from welding electrode or wiring can kill.
 - 1.1 Wear dry insulating gloves. Do not touch electrode with bare hand. Do not wear wet or damaged gloves.
 - 1.2 Protect yourself from electric shock by insulating yourself from work and ground.
 - 1.3 Disconnect input plug or power before working on machine.
- 2 Breathing welding fumes can be hazardous to your health.
 - 2.1 Keep your head out of the fumes.
 - 2.2 Use forced ventilation or local exhaust to remove the fumes.
 - 2.3 Use ventilating fan to remove fumes.
- 3 Welding sparks can cause explosion or fire.
 - 3.1 Keep flammables away from welding. Do not weld near flammables.
 - 3.2 Welding sparks can cause fires. Have a fire extinguisher nearby, and have a watchperson ready to use it.
 - 3.3 Do not weld on drums or any closed containers.
- 4 Arc rays can burn eyes and injure skin.
 - 4.1 Wear hat and safety glasses. Use ear protection and button shirt collar. Use welding helmet with correct shade of filter. Wear complete body protection.
- 5 Become trained and read the instructions before working on the machine or welding.
- 6 Do not remove or paint over (cover) the label.




- 1 Warning! Watch Out! There are possible hazards as shown by the symbols.
- 2 Electric shock from wiring can kill.
- 3 Disconnect input plug or power before working on machine.
- 4 Hazardous voltage remains on input capacitors after power is turned off. Do not touch fully charged capacitors.
- 5 Always wait 60 seconds after power is turned off before working on unit, OR
- 6 Check input capacitor voltage, and be sure it is near 0 before touching any parts.

4/96



- 1 Warning! Watch Out! There are possible hazards as shown by the symbols.
- 2 When power is applied failed parts can explode or cause other parts to explode.
- 3 Flying pieces of parts can cause injury. Always wear a face shield when servicing unit.
- 4 Always wear long sleeves and button your collar when servicing unit.
- 5 After taking proper precautions as shown, connect power to unit.


4/96



- 1 Warning! Watch Out! There are possible hazards as shown by the symbols.
- 2 Falling equipment can cause injury and damage to unit.
- 3 Always lift and support unit using both handles. Keep angle of lifting device less than 60 degrees.
- 4 Use a proper cart to move unit.
- 5 Do not use one handle to lift or support unit.

1/96

2-2. WEEE Label (For Products Sold Within The EU)






























Do not discard product (where applicable) with general waste.

Reuse or recycle Waste Electrical and Electronic Equipment (WEEE) by disposing at a designated collection facility.

Contact your local recycling office or your local distributor for further information.

2-3. Symbols And Definitions

| | | | | | | | |
|---|---------------------------------|---|--|---|------------------------------|---|--|
| A | Amperage |  | Panel |  | Alternating Current (AC) | V | Voltage |
|  | Output |  | Circuit Breaker |  | Remote | I | On |
|  | Off |  | Gas Tungsten Arc Welding | - | Negative |  | Voltage Input |
|  | Direct Current (DC) | + | Positive |  | Inductance |  | Protective Earth (Ground) |
|  | Constant Current |  | Constant Voltage |  | Foot Control |  | Line Connection |
|  | Arc Force |  | Shielded Metal Arc Welding (SMAW) |  | Gas Metal Arc Welding (GMAW) |  | Three Phase Static Frequency Converter-Transformer-Rectifier |
| U₀ | Rated No Load Voltage (Average) | U₁ | Primary Voltage | U₂ | Conventional Load Voltage | X | Duty Cycle |
| Hz | Hertz | IP | Degree Of Protection | I₂ | Rated Welding Current | % | Percent |
|  | Pulsed |  | Lift-Arc Trigger Hold Operation (GTAW) |  | Single Phase |  | Three Phase |
| I_{1max} | Rated Maximum Supply Current | I_{1eff} | Maximum Effective Supply Current |  | Increase |  | Lift-Arc Operation (GTAW) |
|  | Scratch Start TIG |  | Voltage Sensing Feeder | | | | |


SECTION 3 – INTRODUCTION

3-1. Specifications

| Input Power | Rated Output | Voltage Range in CV Mode | Amperage Range in CC Mode | Max. Open-Circuit Voltage | IP Rating | RMS Amps Input at Rated Load Output, 60 Hz 3-Phase at NEMA Load Voltages and Class I Rating | | | | KVA | KW |
|-------------|---------------------------------|--------------------------|---------------------------|---------------------------|-----------|---|-------|-------|-------|------|------|
| | | | | | | 230 V | 380 V | 400 V | 460 V | | |
| 3-Phase | 350 A at 34 VDC, 60% Duty Cycle | 10–38 V | 5–425 A | 75 VDC | 23 | 36.1 | 22.3 | 20.6 | 17.8 | 14.2 | 13.6 |

*See Section 3-3 for Duty Cycle Rating.

3-2. Volt-Ampere Curves




3-3. Duty Cycle And Overheating



Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.


If unit overheats, output stops, a Help message is displayed and cooling fan runs. Wait fifteen minutes for unit to cool. Reduce amperage or voltage, or duty cycle before welding.

NOTICE – Exceeding duty cycle can damage unit and void warranty.




THREE PHASE OPERATION

60% Duty Cycle



Overheating



Ref. 219 523-A

Notes

SECTION 4 – INSTALLATION

4-1. Serial Number And Rating Label Location


The serial number and rating information for this product is located on the rear panel. Use rating label to determine input power requirements and/or rated output. For future reference, write serial number in space provided on back cover of this manual.

4-2. Selecting a Location




Dimensions And Weight


94.8 lb (43 kg)



Movement



⚠ Do not move or operate unit where it could tip.



1 Lifting Handles

Use handles to lift unit.

2 Hand Cart


Use cart or similar device to move unit.

3 Line Disconnect Device

Locate unit near correct input power supply.


⚠ Special installation may be required where gasoline or volatile liquids are present – see NEC Article 511 or CEC Section 20.

Location



loc_2 3/96 - Ref. ST-151 556 / Ref. 803 879-B

4-3. Connecting 3-Phase Input Power



⚠ Installation must meet all National and Local Codes – have only qualified persons make this installation.

⚠ Disconnect and lockout/tagout input power before connecting input conductors from unit.

⚠ Always connect green or green/yellow conductor to supply grounding terminal first, and never to a line terminal.

ℹ The Auto-Line circuitry in this unit automatically adapts the power source to the primary voltage being applied. Check input voltage available at site. This unit can be connected to any input power between 208 and 575 VAC without removing cover to relink the power source.

For Three-Phase Operation

- 1 Input Power Cord.
- 2 Disconnect Device (switch shown in the OFF position)
- 3 Green Or Green/Yellow Grounding Conductor
- 4 Disconnect Device Grounding Terminal
- 5 Input Conductors (L1, L2 And L3)
- 6 Disconnect Device Line Terminals

Connect green or green/yellow grounding conductor to disconnect device grounding terminal first.

Connect input conductors L1, L2, and L3 to disconnect device line terminals.

7 Overcurrent Protection

Select type and size of overcurrent protection using Section 4-4 (fused disconnect switch shown).

Close and secure door on disconnect device. Remove lockout/tagout device, and place switch in the On position.

Tools Needed:



4-5. Weld Output Terminals And Selecting Cable Sizes



⚠️ ARC WELDING can cause Electromagnetic Interference.

To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor. Locate welding operation 100 meters from any sensitive electronic equipment. Be sure this welding machine is installed and grounded according to this manual. If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.




Weld Output Terminals

⚠️ Turn off power before connecting to weld output terminals.

⚠️ Do not use worn, damaged, undersized, or poorly spliced cables.

Weld Cable Size** and Total Cable (Copper) Length in Weld Circuit Not Exceeding***

| Welding Amperes | 100 ft (30 m) or Less | | | | | | | 150 ft (45 m) | | 200 ft (60 m) | | 250 ft (70 m) | | 300 ft (90 m) | | 350 ft (105 m) | | 400 ft (120 m) | | |
|-----------------|-----------------------|--|----------------------|--|----------------------|--|------------------|---------------|-------------------|---------------|-------------------|---------------|-------------------|---------------|-------------------|----------------|--|----------------|--|--|
| | 10 – 60% Duty Cycle | | 60 – 100% Duty Cycle | | 10 – 100% Duty Cycle | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| 100 | 4 (20) | | 4 (20) | | 4 (20) | | 3 (30) | | 2 (35) | | 1 (50) | | 1/0 (60) | | 1/0 (60) | | | | | |
| 150 | 3 (30) | | 3 (30) | | 2 (35) | | 1 (50) | | 1/0 (60) | | 2/0 (70) | | 3/0 (95) | | 3/0 (95) | | | | | |
| 200 | 3 (30) | | 2 (35) | | 1 (50) | | 1/0 (60) | | 2/0 (70) | | 3/0 (95) | | 4/0 (120) | | 4/0 (120) | | | | | |
| 250 | 2 (35) | | 1 (50) | | 1/0 (60) | | 2/0 (70) | | 3/0 (95) | | 4/0 (120) | | 2 ea. 2/0 (2x70) | | 2 ea. 2/0 (2x70) | | | | | |
| 300 | 1 (50) | | 1/0 (60) | | 2/0 (70) | | 3/0 (95) | | 4/0 (120) | | 2 ea. 2/0 (2x70) | | 2 ea. 3/0 (2x95) | | 2 ea. 3/0 (2x95) | | | | | |
| 350 | 1/0 (60) | | 2/0 (70) | | 3/0 (95) | | 4/0 (120) | | 2 ea. 2/0 (2x70) | | 2 ea. 3/0 (2x95) | | 2 ea. 3/0 (2x95) | | 2 ea. 4/0 (2x120) | | | | | |
| 400 | 1/0 (60) | | 2/0 (70) | | 3/0 (95) | | 4/0 (120) | | 2 ea. 2/0 (2x70) | | 2 ea. 3/0 (2x95) | | 2 ea. 4/0 (2x120) | | 2 ea. 4/0 (2x120) | | | | | |
| 500 | 2/0 (70) | | 3/0 (95) | | 4/0 (120) | | 2 ea. 2/0 (2x70) | | 2 ea. 3/0 (2x95) | | 2 ea. 4/0 (2x120) | | 3 ea. 3/0 (3x95) | | 3 ea. 3/0 (3x95) | | | | | |
| 600 | 3/0 (95) | | 4/0 (120) | | 2 ea. 2/0 (2x70) | | 2 ea. 3/0 (2x95) | | 2 ea. 4/0 (2x120) | | 3 ea. 3/0 (3x95) | | 3 ea. 4/0 (3x120) | | 3 ea. 4/0 (3x120) | | | | | |



Output Receptacles

* This chart is a general guideline and may not suit all applications. If cable overheats, use next size larger cable.





**Weld cable size (AWG) is based on either a 4 volts or less drop or a current density of at least 300 circular mils per ampere.

() = mm² for metric use

***For distances longer than those shown in this guide, call a factory applications representative at 920-735-4505.


S-0007-F-

4-6. Remote 14 Receptacle Information

|  |  REMOTE 14 | Socket* | Socket Information |
|--|---|---------|--|
| | 24 VOLTS AC  OUTPUT (CONTACTOR) | | A |
| B | | | Contact closure to A completes 24 volts AC contactor control circuit. |
| 115 VOLTS AC  OUTPUT (CONTACTOR) | | I | 115 volts AC. Protected by circuit breaker CB1. |
| | | J | Contact closure to I completes 115 volts AC contactor control circuit. |
| REMOTE OUTPUT CONTROL | | C | Output to remote control; 0 to +10 volts DC, +10 volts DC in MIG mode. |
| | | D | Remote control circuit common. |
| | | E | 0 to +10 volts DC input command signal from remote control. |
| A/V AMPERAGE VOLTAGE | | F | Current feedback; +1 volt DC per 100 weld amperes. |
| | | H | Voltage feedback; +1 volt DC per 10 weld volts. |
| GND | | G | Circuit common for 24 and 115 volts AC circuits. |
| | | K | Chassis common. |

*The remaining sockets are not used.

4-7. 115 Volts AC Duplex Receptacle And Circuit Breakers



1 115 V 10 Amp. AC Receptacle

Power is shared between duplex receptacle and Remote 14 receptacle (see Section 4-6).

2 Circuit Breaker CB1

3 Circuit Breaker CB2



CB1 protects duplex receptacle and 115 volts AC portion of Remote 14 receptacle from overload.

CB2 protects 24 volts AC portion of Remote 14 receptacle from overload.

Press button to reset breaker.

Ref. 803 879-B

4-8. Optional Gas Valve Operation And Shielding Gas Connection



Obtain gas cylinder and chain to running gear, wall, or other stationary support so cylinder cannot fall and break off valve.

- 1 Cylinder
- 2 Regulator/Flowmeter
- 3 Gas Hose Connection

Install so face is vertical. Fitting has 5/8-18 right-hand threads. Obtain and install gas hose.

- 4 Gas In Fitting
- 5 Gas Out Fitting

The Gas In and Gas Out fittings have 5/8-18 right-hand threads. Obtain proper size, type, and length hose and make connections as follows:

Connect hose from shielding gas supply regulator/flowmeter to Gas In fitting.

Connect hose coupler to torch. Connect one end of gas hose to hose coupler. Connect remaining end of gas hose to Gas Out fitting.

Operation

The gas solenoid controls gas flow during the TIG process as follows:

Remote TIG

Gas flow starts with remote contactor on.

Gas flow stops at end of post-flow if current was detected, or with remote contactor off if no current was detected.

Lift-Arc Trigger Hold TIG

Gas flow starts when output switch is depressed.

Gas flow stops at end of post-flow.

Scratch Start TIG

Gas flow starts when current is detected.


Gas flow stops at end of post-flow.

Post-flow time is factory set to 5 seconds per 100 amps of weld current. The minimum post-flow time is 5 seconds. The maximum post-flow is 20 seconds (post flow settings are not adjustable by the end user).

SECTION 5 – OPERATION

5-1. Front Panel Controls

1 Power Switch

 The fan motor is thermostatically controlled and only runs when cooling is needed.

2 Voltmeter

3 Ammeter

4 V/A (Voltage/Amperage) Adjustment Control

5 Mode Switch

The Mode switch setting determines both the process and output On/Off control (see Section 5-3).

For Air Carbon Arc (CAC-A) cutting and gouging, place switch in Stick position. For best results, place Arc Control in the maximum position.

tion.

6 Remote 14 Receptacle

For remote control, make connections to Remote 14 receptacle. In TIG modes and the REMOTE STICK mode, remote control is a percent of V/A Adjust control setting (value selected on V/A Adjust is maximum available on remote). In ELECTRODE HOT STICK mode the remote control is not used. In the MIG mode, remote control provides full range of unit output regardless of V/A Adjust control setting.

7 Arc Control

Control adjusts Dig when Stick or CC mode is selected on mode switch. When set towards minimum, short-circuit amperage at low arc



voltage is the same as normal welding amperage.

When set towards maximum, short-circuit amperage is increased at low arc voltage to assist with arc starts as well as reduce sticking while welding.

Select setting best suited for application.


Control adjusts inductance when MIG or V-Sense Feeder position is selected on the mode switch. Inductance determines the “wetness” of the weld puddle. When set towards maximum, “wetness” (puddle fluidity) increases.

When Pulsed MIG or one of the TIG modes is selected, this control is not functional.




Ref. 803 692-B / Ref. 219 341-A

5-2. Meter Functions

 The meters display the actual weld output values for approximately three seconds after the arc is broken.


| Mode | Meter Reading At Idle | | Meter Reading While Welding | |
|---------------------------|--|----------------------------------|----------------------------------|--------------------------------|
| Scratch Start TIG | V 71.7 Actual Volts (OCV) | A 85 Preset Amps | V 10.3 Actual Volts | A 85 Actual Amps |
| Lift-Arc Trigger Hold TIG | V Blank | A 85 Preset Amps | V 10.3 Actual Volts | A 85 Actual Amps |
| TIG | V Blank | A 85 Preset Amps | V 10.3 Actual Volts | A 85 Actual Amps |
| MIG | V 24.5 Preset Volts | A Blank | V 24.5 Actual Volts | A 250 Actual Amps |
| Pulsed MIG | V PPP Pulse Display | A PPP Pulse Display | V 24.5 Actual Volts | A 250 Actual Amps |
| CC | V Blank | A 85 Preset Amps | V 24.5 Actual Volts | A 85 Actual Amps |
| Stick | V 71.7 Actual Volts (OCV) | A 85 Preset Amps | V 24.5 Actual Volts | A 85 Actual Amps |
| V-Sense Feeder | V 71.7 Flashes OCV And Preset | A Blank | V 24.5 Actual Volts | A 250 Actual Amps |

5-3. Mode Switch Settings

 The Stick and CC modes provide the Adaptive Hot Start™ feature, which automatically increases the output amperage at the start of a weld should the start require it. This eliminates electrode sticking at arc start.


| Mode Switch Setting | Process | Output On/Off Control |
|---------------------------|--|-----------------------|
| Scratch Start TIG | GTAW | Electrode Hot |
| Lift-Arc Trigger Hold TIG | GTAW – See Section 5-4 | At Remote 14 |
| TIG | GTAW With HF Unit, Pulsing Device, Or Remote Control | At Remote 14 |
| MIG | GMAW | At Remote 14 |
| Pulsed MIG | GMAW-P (Requires an external pulsing device.) | At Remote 14 |
| CC | Stick (SMAW) With Remote On/Off | At Remote 14 |
| Stick | SMAW | Electrode Hot |
| V-Sense Feeder | MIG (GMAW) With Voltage Sensing Wire Feeder | Electrode Hot |

5-4. Lift-Arc Trigger Hold TIG



1 TIG Electrode

2 Workpiece

 Procedure requires:

  control

Start sequence:

- Touch tungsten electrode to workpiece at weld start point.
- Momentarily depress output switch.
- Slowly lift electrode. An arc will form when electrode is lifted.
- To stop welding, momentarily depress output switch and output will shut off.

Note: If output switch is momentarily depressed and tungsten is not touching workpiece:

Do not touch tungsten to work.

Output will shut off in 3 seconds.

Start sequence over.

Ref. S-156 279

5-5. Stick Start Procedure




With Stick selected, start arc as follows:

- 1 Electrode
- 2 Workpiece
- 3 Arc

Drag electrode across workpiece like striking a match; lift electrode slightly after touching work. If arc goes out electrode was lifted to high. If electrode sticks to workpiece, use a quick twist to free it.













Low OCV Stick

The unit can be optionally configured for low open circuit voltage (OCV) operation. When the unit is configured for low OCV operation only a low sensing voltage (approximately 15 VDC) is present between the electrode and the workpiece prior to the electrode touching the workpiece. Consult a Factory Authorized Service Agent for information regarding how to configure the unit for low OCV stick welding operation.





SECTION 6 – MAINTENANCE & TROUBLESHOOTING


6-1. Routine Maintenance


| | | |
|--|--|---|
|  |  <p>Disconnect power before maintaining.</p> | <p> <i>Maintain more often during severe conditions.</i></p> |
| <p> 3 Months</p> | | |
| <p>  Replace Damaged Or Unreadable Labels</p> | <p> Repair Or Replace Cracked Cables</p> | <p> Replace Cracked Torch Body</p> |
| <p> Repair Or Replace Cracked Cables And Cords</p> | | |
| <p> Clean And Tighten Weld Connections</p> | | |
| <p> 6 Months</p> | | |
| <p> Blow Out Inside</p> | | |

6-2. Blowing Out Inside Of Unit

| | |
|--|--|
|  | <p> Do not remove case when blowing out inside of unit.</p> <p>To blow out unit, direct airflow through front and back louvers as shown.</p> |
| <p>Ref. 803 879-B</p> | |

6-3. Voltmeter/Ammeter Help Displays



 All directions are in reference to the front of the unit. All circuitry referred to is located inside the unit.

1 Help 1 Display

Indicates a malfunction in the primary power circuit. If this display is shown, contact a Factory Authorized Service Agent.

2 Help 2 Display

Indicates a malfunction in the thermal protection circuitry. If this display is shown, contact a Factory Authorized Service Agent.

3 Help 3 Display

Indicates the left side of the unit has overheated. The unit has shut down to allow the fan to cool it (see Section 3-3). Operation will continue when the unit has cooled.

4 Help 5 Display

Indicates the right side of the unit has overheated. The unit has shut down to allow the fan to cool it (see Section 3-3). Operation will continue when the unit has cooled.

5 Help 6 Display


Indicates operation at maximum input current. The unit has a maximum allowable input

current limit. As the line voltage decreases, the required input current increases. If the line voltage is too low, the output power is limited by the input current. When this limit is reached, the unit automatically reduces output power to continue operation. If this display is shown, have a qualified electrician check the input voltage.

6 Help 8 Display


Indicates a malfunction in the secondary power circuit of the unit. If this display is shown, contact a Factory Authorized Service Agent.

6-4. Troubleshooting



| Trouble | Remedy |
|--|---|
| No weld output; unit completely inoperative. | Place line disconnect switch in On position (see Section 4-3). |
| | Check and replace line fuse(s), if necessary, or reset circuit breaker (see Section 4-3). |
| | Check for proper input power connections (see Section 4-3). |
| No weld output; meter display On. | Input voltage outside acceptable range of variation (see Sections 4-3, 4-4). |
| | Check, repair, or replace remote control. |
| | Unit overheated. Allow unit to cool with fan On (see Section 3-3). |
| Erratic or improper weld output. | Use proper size and type of weld cable (see Section 4-5). |
| | Clean and tighten all weld connections. |
| | Check for correct polarity. |
| No 115 volts AC output at duplex receptacle or Remote 14 receptacle. | Reset circuit breaker CB1 (see Section 4-7). |
| No 24 volts AC output at Remote 14 receptacle. | Reset circuit breaker CB2 (see Section 4-7). |

SECTION 7 – ELECTRICAL DIAGRAM

| | |
|---|--|
|  | WARNING |
| | <ul style="list-style-type: none"> Do not touch live electrical parts. Disconnect input power or stop engine before servicing. Do not operate with covers removed. Have only qualified persons install, use, or service this unit. |
| ELECTRIC SHOCK HAZARD | |






Figure 7-1. Circuit Diagram



SECTION 8 - PARTS LIST



Ref. 803 850-F

Figure 8.1. Parts Assembly

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 8.1. Parts Assembly

| | | | | |
|----|--------|----------|---|---|
| 1 | | 216 034 | Wrapper (Includes Insulators and Safety Labels) | 1 |
| | | 175 256 | Insulator, Side Rh (Not Shown) | 1 |
| | | 178 551 | Insulator, Side (Not Shown) | 1 |
| 2 | | 179 310 | Label, General Precautionary Wordless, Intl, Small | 2 |
| 3 | | 179 309 | Label, Caution Falling Equipment Can Injure-wordles | 2 |
| 4 | | 195 585 | Handle, Rubberized Carrying | 2 |
| 5 | | 135 483 | Label, Important Remove These Two Handle Screws | 2 |
| 6 | R3/C4 | 233 052 | Resistor/Capacitor | 1 |
| 7 | | Deleted | | |
| 8 | SR1 | 201 530 | Kit, Diode Fast Recovery Bridge | 1 |
| 9 | | 199 840 | Bus Bar, Diode | 2 |
| 10 | | 196 355 | Insulator, Screw | 4 |
| 11 | D1,D2 | 201 531 | Kit, Diode Power Module | 2 |
| 12 | RT1 | 219 343 | Thermistor, NTC 30K Ohm @ 25 Deg C 18in Lead | 1 |
| 13 | CR1 | 198 549 | Relay, Encl 24VDC Spst 35A/300VAC 4Pin Flange Mtg | 1 |
| 14 | | 227 927 | Label, Warning Electric Shock/Exploding Parts-wdles | 1 |
| 15 | | 010 546 | Bushing, Snap-In Nyl .375 Id X .500 Mtg Hole | 1 |
| 16 | L4 | 218 020 | Inductor, Boost | 1 |
| 17 | | 179 276 | Bushing, Snap-In Nyl 1.000 Id X 1.375 Mtg Hole Cent | 3 |
| 18 | | 170 647 | Bushing, Snap-In Nyl 1.312 Id X 1.500 Mtg Hole | 1 |
| 19 | L3 | 212 150 | Inductor, Output | 1 |
| 20 | T1 | 212 132 | XFMR, HF Litz/Litz W/Boost | 1 |
| 21 | | 225 097 | Heat Sink, Lh Rect | 1 |
| 22 | L1 | 212 091 | Inductor, Input | 1 |
| 23 | | 083 147 | Grommet, Scr No 8/10 Panel Hole .312 Sq .500 High | 4 |
| 24 | PC1 | 229 983 | Circuit Card Assy, Control/Aux Power W/Program | 1 |
| | | 216 113 | Stand-Off Support, PC Card .187 Dia W/P&I .375 | 2 |
| | PLG1 | 115 091 | Housing Plug+Pins (Service Kit) RC1 | 1 |
| | PLG2 | 201 665 | Housing Plug+Pins (Service Kit) RC2 | 1 |
| | PLG3 | 131 056 | Housing Plug+Pins (Service Kit) RC3 | 1 |
| | PLG5 | 131 204 | Housing Plug+Pins (Service Kit) RC5 | 1 |
| | PLG7 | 131 054 | Housing Plug+Pins (Service Kit) RC7 | 1 |
| | PLG8 | 131 054 | Housing Plug+Pins (Service Kit) RC8 | 1 |
| | PLG9 | 115 093 | Housing Plug+Pins (Service Kit) RC9 | 1 |
| | PLG10 | 115 094 | Housing Plug+Pins (Service Kit) RC10 | 1 |
| | PLG11 | 115 094 | Housing Plug+Pins (Service Kit) RC11 | 1 |
| | PLG12 | 115 092 | Housing Plug+Pins (Service Kit) RC12 | 1 |
| 25 | | 212 072 | Bracket, Mtg Capacitor/Pc Board | 1 |
| 26 | C12,13 | 219 930 | Kit, Capacitor Elclt Replacement (Includes) | 1 |
| | | 193 738 | Capacitor, Elclt 1800 Uf 500 VDC Can 2.52 Dia | 2 |
| | | 217 040 | Nut, Nylon M12 Thread Capacitor Mounting | 2 |
| 27 | RC2 | 604 176 | Rcpt, Str Dx Grd 2P3W 15A 125V *5-15R | 1 |
| 28 | CB2 | 083 432 | Circuit Breaker, Man Reset 1P 10A 250VAC Frict | 1 |
| 29 | CB1 | 083 432 | Circuit Breaker, Man Reset 1P 10A 250VAC Frict | 1 |
| 30 | | +219 470 | Panel, Rear CE W/Aux | 1 |
| 31 | | 219 335 | Label, Warning Electric Shock Can Kill CE Wordless | 1 |
| 32 | | | Nameplate, Rear Aux/Gas/CE (Order by Model and Serial Number) | 1 |
| 33 | | 175 282 | Cover, Receptacle Weatherproof Duplex Rcpt | 1 |
| 34 | | 212 945 | Label, Warning Incorrect Connections CE Wordless | 1 |
| 35 | | 215 980 | Bushing, Strain Relief .709/.984 Id X1.375 Mtg Hole | 1 |
| 36 | | 219 487 | Cable, Power 12Ft 8Ga 4C (Non-Stripped End) | 1 |

+When ordering a component originally displaying a precautionary label, the label should also be ordered.
BE SURE TO PROVIDE MODEL AND SERIAL NUMBER WHEN ORDERING REPLACEMENT PARTS.

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 8.1. Parts Assembly (Continued)

| | | | | |
|----|--------|----------|---|---|
| 37 | | 234 126 | Nut, Conduit 1.000 Npt Knurled | 1 |
| 38 | T2 | 211 968 | XFMR, Control Toroidal 665 VAC Pri 1536 Va 60 Hz | 1 |
| | | 212 947 | Plate, Mtg Toroid XFMR | 1 |
| 39 | L2 | 218 018 | Inductor, Pre-Regulator | 1 |
| 40 | | 218 566 | Gasket, Inductor Mounting | 1 |
| 41 | CT1 | 196 231 | XMFR, Current Sensing 200/1 | 1 |
| 42 | C15 | 196 143 | Capacitor, Polyp Met Film 16. Uf 400 VAC 10% | 1 |
| 43 | | 219 472 | Bracket, Mtg Capacitor Series | 1 |
| 44 | RT2 | 199 798 | Thermistor, NTC 30K Ohm @ 25 Deg C 18in Lead | 1 |
| 45 | PC2 | 229 987 | Circuit Card Assy, Interconnect W/Label & Clips (Includes) | 1 |
| 46 | | 219 335 | Label, Warning Electric Shock Can Kill Ce Wordless | 1 |
| | | 223 343 | Clip, Wire Stdf .40-.50 Bndl .156Hole .031-.078Thk | 2 |
| | PLG13 | 130 203 | Housing Plug+Pins (Service Kit) RC1 | 1 |
| | PLG14 | 201 665 | Housing Plug+Pins (Service Kit) RC2 | 1 |
| | PLG15 | 115 092 | Housing Plug+Pins (Service Kit) RC3 | 1 |
| | PLG20 | 115 093 | Housing Plug+Pins (Service Kit) RC6 | 1 |
| 47 | | 153 403 | Bushing, Snap-In Nyl .750 Id X 1.000 Mtg Hole Cent | 3 |
| 48 | RM1 | 205 751 | Module, Power Resistor W/Plug | 1 |
| 49 | | 217 625 | Kit, Input/Pre-Regulator And Inverter Module (Includes) | 1 |
| | | | MOD 1, SKiip 83 HEC | 1 |
| | | | MOD 2, SKiip 83 EC | 1 |
| 50 | | 212 206 | Windtunnel, Rh | 1 |
| 51 | | 196 330 | Heat Sink, Power Module | 1 |
| 52 | | +175 132 | Base | 1 |
| 53 | | 229 325 | Foot, Mtg Unit | 4 |
| 54 | | 176 736 | Screw, Mtg Foot | 4 |
| 55 | | 212 073 | Label, Warning Exploding Parts Can CE Wordless | 1 |
| 56 | | 212 074 | Bus Bar, Output | 1 |
| 57 | HD1 | 182 918 | Transducer, Current 400A Module Supply V +/- 15V | 1 |
| 58 | PC3 | 229 985 | Circuit Card Assy, Front Panel & Display W/Program | 1 |
| | PLG18 | 131 204 | Housing Plug+Pins (Service Kit) RC2 | 1 |
| | RC50 | 210 233 | Rcpt, W/Pins (Service Kit) | 1 |
| | PLG21 | 212 088 | Plug, W/Leads | 1 |
| | RC21 | 167 640 | Housing Plug+Pins (Service Kit) | 1 |
| 59 | S1 | 231 191 | Switch, Tgl 3Pst 50A 600VAC Scr Term Wide Tgl | 1 |
| 60 | | 176 226 | Insulator, Switch Power | 1 |
| 61 | FM1 | 196 313 | Fan, Muffin 115V 50/60Hz 3000 RPM 6.378 Mtg Holes | 1 |
| | PLG16 | 131 054 | Housing Plug+Pins (Service Kit) | 1 |
| | RC16 | 135 635 | Housing Plug+Pins (Service Kit) | 1 |
| 62 | | 208 967 | Rcpt Assy, Tw Lk Insul Fem (Dinse Type) 50/70 Series (Includes) | 2 |
| | | 208 968 | Rcpt, Tw Lk Insul W/O-Ring | 1 |
| | | 185 712 | Insulator, Bulkhead Front | 1 |
| | | 185 713 | Insulator, Bulkhead Rear | 1 |
| | | 185 714 | Washer, Tooth 22mmid X 31.5mmod 1.310-1mmt Intern | 1 |
| | | 185 717 | Nut, M20-1.5 1.00Hex .19H Brs Locking | 1 |
| | | 185 718 | O-Ring, 0.989 Id X 0.070 H | 1 |
| | | 186 228 | O-Ring, 0.739 Id X 0.070 H | 1 |
| 63 | | 212 070 | Panel, Front Standard | 1 |
| 64 | C5,6,7 | 233 668 | Capacitor Assy, W/Plug & Leads (Voltage Feedback) | 1 |
| 65 | | 216 112 | Fastener, Panel Receptacle Quick Access | 2 |
| 66 | | | Nameplate (Order by Model and Serial Number) | 1 |
| 67 | | | Nameplate, Connection (Order by Model and Serial Number) | 1 |
| 68 | | | Nameplate, Power (Order by Model and Serial Number) | 1 |
| 69 | | 174 991 | Knob, Pointer 1.250 Dia X .250 Id W/Spring Clip-.21 | 2 |

+When ordering a component originally displaying a precautionary label, the label should also be ordered.
BE SURE TO PROVIDE MODEL AND SERIAL NUMBER WHEN ORDERING REPLACEMENT PARTS.


| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 8.1. Parts Assembly (Continued)

| | | | | |
|--------|-------|----------|---|---|
| ... 70 | | 174 992 | .. Knob, Pointer .840 Dia X .250 Id W/Spring Clip-.21 | 1 |
| ... 71 | | 218 041 | .. Door, W/Quick Access Ball Fasteners | 1 |
| ... 72 | | 175 138 | .. Box, Louver | 1 |
| ... 73 | | | Label (Order by Model and Serial Number) | 1 |
| ... 74 | | +212 207 | .. Windtunnel, Lh | 1 |
| ... 75 | | 211 503 | .. Insulator, Heat Sink | 1 |
| ... 76 | C8 | 219 191 | .. Capacitor, Polyp Film .001 Uf 2000V W/Terms | 1 |
| ... 77 | L6 | 131 447 | .. Core, Toroidal 1.332 Id X 1.932 Od X .625 Thk | 1 |
| ... 78 | L5,L7 | 199 122 | .. Core, Toroidal .750 Id X 1.450 Od X .544 Thk | 2 |
| ... 79 | | 083 147 | .. Grommet, Scr No 8/10 Panel Hole .312 Sq .500 High | 2 |
| ... 80 | | 219 471 | .. Bracket, Mtg Filter Board | 1 |
| ... 81 | | 219 473 | .. Bracket, Mtg CE Filter Ground Plane | 1 |
| ... 82 | PC4 | 229 989 | .. Circuit Card Assy, Filter | 1 |
| ... 83 | | 227 746 | .. Gasket, Inductor Mounting | 1 |

+When ordering a component originally displaying a precautionary label, the label should also be ordered.
BE SURE TO PROVIDE MODEL AND SERIAL NUMBER WHEN ORDERING REPLACEMENT PARTS.

Notes



MATERIAL THICKNESS GAUGE

TRUE BLUE[®]

WARRANTY

Effective January 1, 2009

This limited warranty supersedes all previous Miller warranties and is exclusive with no other guarantees or warranties expressed or implied.

LIMITED WARRANTY – Subject to the terms and conditions below, ITW Welding Products Italy warrants to its original retail purchaser that new Miller equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by Miller. **THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.**

Within the warranty periods listed below, Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Miller must be notified in writing within thirty (30) days of such defect or failure, at which time Miller will provide instructions on the warranty claim procedures to be followed.

Miller shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the date the equipment was delivered to the original retail purchaser, not to exceed eighteen months after the equipment is shipped to an International distributor.

1. 5 Years Parts — 3 Years Labor
 - * Original main power rectifiers limited to only include SCRs, diodes, and discrete rectifier components where applicable
 - * Inverters (Input and Output Rectifiers Only)
2. 3 Years — Parts and Labor
 - * Transformer/Rectifier Power Sources
 - * Plasma Arc Cutting Power Sources
 - * Semi-Automatic and Automatic Wire Feeders
 - * Inverter Power Sources (Unless Otherwise Stated)
 - * Water Coolant Systems (Integrated)
 - * Engine Driven Welding Generators
(NOTE: Engines are warranted separately by the engine manufacturer.)
3. 2 Years — Parts and Labor
 - * Motor Driven Guns (w/exception of Spoolmate Spoolguns)
 - * Process Controllers
 - * RFCS Foot Controls
 - * IHPS Power Sources and Coolers
 - * Water Coolant Systems (Non-Integrated)
 - * HF Units
 - * Running Gear/Trailers
 - * Field Options
(NOTE: Field options are covered under True Blue[®] for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)
4. 1 Year — Parts and Labor Unless Specified
 - * DC 253 & 403 Rectifier (April 06>)
 - * Migmatic 171 (April 06>)
5. 6 Months — Batteries
6. 90 Days — Parts
 - * MIG Guns
 - * Induction Heating Coils and Blankets
 - * Remote Controls
 - * Accessory (Kits)
 - * Replacement Parts (No labor)
 - * Spoolmate Spoolguns
 - * Canvas Covers

Miller's True Blue[®] Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, slip rings, relays or parts that fail due to normal wear.**
2. Items furnished by Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than Miller, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MILLER PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at Miller's option: (1) repair; or (2) replacement; or, where authorized in writing by Miller in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Miller's option of repair or replacement will be F.O.B., Factory at ITW Welding Products Group Europe or F.O.B. at a Miller authorized service facility as determined by Miller. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.





Owner's Record

Please complete and retain with your personal records.

Model Name

Serial/Style Number

Purchase Date

(Date which equipment was delivered to original customer.)

Distributor

Address

Country

Zip/Postal Code



For Service

Contact a DISTRIBUTOR or SERVICE AGENCY near you.

Always provide Model Name and Serial/Style Number.

Contact your Distributor for:

Welding Supplies and Consumables

Options and Accessories

Service and Repair

Replacement Parts

Owner's Manuals

Contact the Delivering Carrier to:

File a claim for loss or damage during shipment.

For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department.

ITW Welding Products Italy S.r.l.

Via Privata Iseo, 6/E

20098 San Giuliano

Milanese, Italy

Phone: 39 (0) 2982901

Fax: 39 (0) 298290-203

email: miller@itw-welding.it

